



Glistening Body Oil

Reveal your feminine side with this remarkably strong shimmering body oil! **Kraton G1701** is a linear di-block copolymer based on styrene and ethylene/propylene, which thickens to thixotropic greases particularly suitable for apolar oils. **Ercarel DOE V** combines a very high spreadability with good stability and dry skin feel. **Gemseal 40** has also a dry touch and a significant evaporation rate boosted with the presence of **Methylal**. **Marcol 82** is a cost effective light white oil. **Kraton G1701** offers also suspension properties. **SHINESTAR T90**, a new generation silver pigment based on Calcium Aluminum Borosilcate coated with silver, brings the incredible, jewel like shimmer into the formulation.

	Trade name	INCI name	Supplier	%
A	1 Ercarel DOE V	Dicaprylyl Ether	Erca / Univar*	43.95
	2 Marcol 82	Paraffinum Liquidum	ExxonMobil / Univar*	20.00
	3 Gemseal 40	C15-C19 Alkane	Total / Univar*	20.00
	4 KPC MT50	Mixed Tocopherol, Soybean Oil	Kemin / Univar*	0.50
B	5 Kraton™ G1701 SQR IIII	Hydrogenated Styrene/Isoprene Copolymer	Kraton / Univar*	5.00
C	6 Methylal Pure Grade Desodorised	Methylal	Lambiotte / Univar*	10.00
	7 Caramel Sale SY149649	Parfum / Fragrance	Kao Fragrances / Univar*	0.50
	8 SHINESTAR T90	Calcium Aluminum Borosilicate, Silver, Tin Oxide	ABC Nanotech / Univar*	0.10

* Please contact your regional Univar sales representative to ensure that mentioned products are distributed in your country.

Procedure (Hot Process)

1. Combine phase A ingredients and heat to 85°C (closed vessel).
2. Disperse B into A with a Silverson equipment at 2000 rpm (85°C-closed vessel).
3. Maintain heat at 85°C while mixing at 4000RPM (Silverson) for 10min (closed vessel).
4. When it is clear and homogeneous, cool down to room temperature and add phase C with gentle stirring.

Stability

Stable at least 2 months at room temperature and 40°C (still ongoing).

Comments

- Viscosity (spindle 3; 60 rpm; 1 min) = 1,300 cPs (78.2%)
- Appealing shimmering body oil where metallic pearl pigments are suspended. A black background of the jar really enhances the sparkling effect.
- Cost effective formula

Reference: 290615.CM(U)B1

Issued by: Univar's European PC Laboratory in Brussels, Belgium

Contact: personalcareEMEA@univar.com | www.univar.com



Disclaimer – Univar BV and its affiliates (“Univar”) offers this suggested formulation as a representative formulation only. It is not a commercialized product. Univar relies on information and data from its suppliers on which to base this suggested formulation, but Univar has not subjected the suggested formulation to any testing for performance, efficacy or safety. Univar makes no warranties, express or implied, related to this suggested formulation, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Additionally, Univar has not done any patent search on the suggested formulation. BEFORE USE, YOU MUST TEST THE FORMULATION, OR ANY VARIANCE THEREOF, TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY. FURTHERMORE, IT IS YOUR RESPONSIBILITY TO OBTAIN ANY NECESSARY GOVERNMENT CLEARANCE, LICENSE OR REGISTRATION. BY TAKING THIS SUGGESTED FORMULATION, YOU HEREBY AGREE TO DEFEND AND HOLD UNIVAR HARMLESS FROM ANY CLAIM OF INTELLECTUAL PROPERTY INFRINGEMENT. Any suggested uses are not inducements to infringe any patent and should not be taken as such. © 2015, Univar Inc. All rights reserved. Univar, the hexagon and the Univar logo are registered trademarks of Univar Inc. Certain trademarks are owned by third parties, are used to identify the goods and services identified by those marks, and are the property of their rightful owners. 00007941-2015